



HANDLE ASSEMBLY DIAGRAM



HANDLE ASSEMBLY PARTS LIST

Index #	Part No.	Description	Qty.
1	TQ22001.3.2-01	Hand shank head	1
2	TQ22001.3.2-04	Down Hand shank	1
3	T32002c-2	Hand shank case	1
4	GB879	Pin	1
5	TQ22001.3-07	Handle	1
6	TQ22001.3-06	Handle case	1
7	TQ22001.3-05	Upper Draw bar	1
8	TQ22001.3-04	Upper connect head	1
9	GB6170	Nut M8	1
10	TQ22001.3-03	Down Draw bar	1
11	TQ22001.3-02	Spring	1
12	TQ22001.3-01	Down connect head	1
13	TQ22001.3.1-04	Upper Hand shank	1
14	GB879	Pin	1
15	GB70	Bolt M5	2
16	TQ22001.3.2-05	Down Handle draw bar	1
17	TQ22001.3.1-06	Connect	2
18	TQ22001.3.1-01	Connect	1
19	GB879	Pin	2
20	TQ22001.3.1-05	Upper Handle draw bar	1
21	GB97.1	Washer 8	1
22	GB818	Bolt M5X10	1


ASSEMBLY DIAGRAM



ASSEMBLY PARTS LIST

Index #	Part No.	Description	Qty.
23	Planking	TQ22001-06	1
24	Press cylinder	TQ35001.1	1
25	Air pump	TY20002.1.2	1
26	Revolving Tie-in	TQ22001.8	1
27	Air hose	TQ22001-07a	1
28	Switch	TQ22001.9a	1
29	bolt M6X12	GB818	4
30	Washer6	GB97.1	4
31	Bolt M12x25	GB5781	4
32	Spring Washer12	GB93	4
33	Washer12	GB97.1	4
34	Bolt M5X12	GB818	4
35	Block 15	GB896	2
36	Wheel Part	TQ22001.5	2
37	Hand Shank Part	TQ22001.3	1
38	Top nut regular board	TQ22001.1.1-01	1
39	Pin	TQ22001-03	3
40	Top nut regular board	TQ22001-02	1
41	Nut M8	GB6170	4
42	Spring Washer 8	GB93	4
43	Washer8	GB97.1	4
44	Regular sleeve	TQ22001-01	2
45	Socket	TQ22001-05	1
46	Bolt	TQ22001-04	1
47	Bracket	TQ22001.4a	1
48	Washer10	GB97.1	4
49	Washer10	GB93	4
50	Bolt M10x16	GB5781	4
51	Left Wallboard	TQ22001.6	1
52	Floor board assembly	TQ22001.7a	1
53	Right Wallboard	TQ22001.10	1
54	Release Valve Rod Assembly	TQ22001.1.2	1

POWER UNIT ASSEMBLY



POWER UNIT PARTS LIST

Index #	Part No.	Description	Qty.
55	TQ22001.1-01	Top Head	1
56	TQ35001.1-01	Screw	1
57	TH930001-07	Bushing	1
58	TQ22001.1-05	Spring Hunger	1
59	TH930001-03	Snap ring	1
60	TQ22001.1.2-01	Release Valve Rod	1
61	TQ35001.1-04	Plunger ring	1
62	TH930001-05	O-Ring	1
63	TQ35001.1-02	Piston rod	1
64	TQ35001.1-03	Spring	2
65	GB5781	Bolt M10X20	2
66	GB41	Nut M10	2
67	TQ35001.1-05	Piston	1
68	TQ35001.1-06	Seal ring	1
69	TQ35001.1-07	Y-Ring	1
70	TQ35001.1.1	Part of Base	1
71	QYL8-29	Oil Plug	1
72	QLZ3.4-13	Valve plug screw	1
73	QLQ2.1-14	O-Ring	1
74	QF4-20	Bolt	1
75	TQ22001.1-31	Spring	1
76	TQ22001.1-24	Spring seat	1
77	GB308	Ball 3	1
78	GB70	Bolt M12X16	1
79	TQ22001.1-18	O-Ring	1
80	TQ22001.1-19	Spring	1
81	GB308	Ball 9	1
82	TQ22001.1-17a	Pin	1
83	GB308	Ball 6	2
84	TQ22001.1-11	Valve block	1
85	TQ22001.1-16	O-ring	3
86	GB93	Spring washer	3
87	GB70	Bolt M8X25	3
88	TQ22001.1-30	Washer	1
89	GB3452.1	O-ring	1
90	TQ22001.1-10	Release Valve	1
91	GB79	Pin	1
92	GB308	Ball 6	1
93	QLQ2.1-17	O ring	1